

DI-10 MULTI MAX CLEAR

Technical Data Sheet

DESCRIPTION:

DI-10 Multi Max Clear is a 4:1 mix Acrylic Urethane Clear designed for overall, multi-panel and panel applications. The clearcoat has excellent leveling properties and superior gloss retention. DI-10 Multi Max Clear can be air dried or forced dried. It is applied as a 2 coat system. (3rd coat optional).

PACKAGING:

| | | |
|---------|----------------------|----------|
| ▶ DI-10 | Multi Max Clear | 1 Gallon |
| ▶ DI-11 | Fast Dry Activator | Quart |
| ▶ DI-12 | Medium Dry Activator | Quart |
| ▶ DI-13 | Slow Dry Activator | Quart |

MIX RATIO:

| | |
|-----------|---|
| ▶ 4 Parts | DI-30 Speed Clear |
| ▶ 1 Part | DI-11, DI-12, DI-13 Clearcoat Activator |

*Can be reduced up to 10% with urethane grade reducer
(Adding reducer will increase V.O.C.'s)*

BASECOAT:

- ▶ All Acrylic and Polyester Basecoat Color Systems

GUN SETUP:

- ▶ Conventional Gravity 1.3mm-1.4mm 40-45 psi @ gun
- ▶ Siphon 1.3mm-1.4mm 40-45 psi @ gun
- ▶ HVLP 1.3mm-1.4mm 8-10 psi @ gun

APPLICATION:

- ▶ Apply 2 full wet coats (3rd coat optional)

DRY TIMES:

| | | |
|-------------------------------------|--|--------------------|
| ▶ AIR DRY | | |
| Flash between coats | | 10-15 minutes |
| Dust Free | | 5-8 minutes |
| Air Dry | | 8-12 hours @ 75°F |
| ▶ EXPRESS DRY | | |
| Flash between coats | | 10-15 minutes |
| Flash before force dry (Purge Time) | | 10-15 minutes |
| Cycle Time | | 25 minutes @ 140°F |

BLENDING:

- ▶ Apply first coat of clearcoat.
- ▶ Extend second coat of clear past first coat.
- ▶ Mix the remaining clearcoat 1:1 with blending solvent.
- ▶ Apply mixture over the edge of the clear with 50% overlap to melt in the edge.
- ▶ To further melt-in the remaining edge, apply 100% blending solvent with 50% overlap.

RECOATABILITY / REPAIR:

- ▶ Baked
After cool down
- ▶ Air Dry
8-12 hours @ 75°F
*If recoating after 24 hours, scuff before applying clearcoat.

SANDING, COMPOUNDING, POLISHING:

- ▶ OPTIMUM TIMES
Express Dry: After cool down
Air Dry: 8-12 hours @ 75°F
- ▶ SANDING
For dirt removal, lightly denib sand with 1500 / 2000 grit wet sandpaper.
- ▶ COMPOUNDING
Using a finishing compound apply a thin ribbon of material to the area to be polished. Use a foam compounding or polishing pad. Maintain buffer speed at 1500-2200 rpm. Remove excess compound with a clean soft cloth before applying polish.
- ▶ POLISHING
Using a finishing polish and a foam polishing pad apply a ribbon of material to work a 2-3 foot square area. Maintain buffer speed at 1200-1800 rpm. Keep the buffer moving at all times. Use a pattern utilizing a 50% overlap. Wipe off excess polish with a clean soft cloth. Hand buff with a clean soft cloth as a finishing touch.

TECHNICAL PRODUCT INFORMATION:

- ▶ Dust Free 5-8 minutes
- ▶ Flash Time 10 minutes
- ▶ Tack Free 5-8 mins. @ 75°F
- ▶ Purge Time 10-15 mins.
- ▶ Bake 30 min. @ 140°F
- ▶ Air Dry 8-12 hrs. @ 75°F
- ▶ Pot Life: 5 hours @ 68°F-75°F
- ▶ Shelf Life: One Year (unopened)

Health and Safety:

See Material Safety Data Sheet and labels for additional safety information and handling instructions.

- * The contents of this package may have to be blended with other components before the product can be used. Before opening the packages, be sure you understand the warning messages on the labels and MSDS's of all components, since the mixture will have the hazards of all its parts.
- * Improper handling and use, for example, poor spray technique, inadequate engineering controls and or lack of Personal Protective Equipment (PPE), may result in hazardous conditions or injury.
- * Follow spray equipment manufacturer's instructions to prevent personal injury or fire.
- * Provide adequate ventilation for health and fire hazard control.
- * Follow company, product MSDS and respirator manufacturer's recommendations for selection and proper use of respiratory protection. Be sure employees are adequately trained on the safe use of respirators per company and regulatory requirements.
- * Wear appropriate PPE such as eye and skin protection. In the event of injury, see first aid procedures on MSDS.
- * Always observe all applicable precautions and follow good safety and hygiene practices.
- * Material Safety Data Sheets are available at www.medallionrefinish.com.

FOR PROFESSIONAL USE ONLY

Distinctive Image * Dutch Square Industrial Park * Wilmington, NC 28405
1.901.395.5878